

MagPro Wall Covering - Installation Guide

Install MagPro dry erase magnetically receptive wall covering with Flexi sheet adhesive, we recommend using a flexi sheet adhesive.

Preparation:

- Remove all old backing paper from wall surface. Ensure hanging surface is smooth, clean, dry in depth, of a uniform colour and in a sound condition.
- Surface should be free from contaminants such as dirt, dust, grease, mildew, ink stains; etc - any of these can prevent adhesion taking place.
- Wash with detergent solution, rinse and allow to dry.
- Fill cracks and holes with a proprietary filler in accordance with the manufacturer's instructions.
- Treat any areas showing mould growth.
- Ensure floors are swept clean to avoid dirt gathering at skirting level.
- Ensure that you are installing under adequate lighting conditions.
- Site temperature should not be below 12°C (55°F). Avoid excessive heat until adhesive is fully dried

Surfaces:

Emulsion Paint: If the wall is sound and in good condition, the adhesive can be applied straight on to emulsion paint. If there is any damage, flakiness it is best to prime the surface. Abrade surface to provide a good key. Wash and dry thoroughly, apply one coat of water-based primer we recommend zinsser bulls eye 1-2-3.

- Depending on what type of surface you are installing this product onto, the adhesive used will vary
- If applying directly onto a wall use the water based adhesive
- If applying onto a substrate such as MDF or Foamex first, use the solvent based adhesive.

Hanging Instructions:

- Cut the Flexi sheet to required length
- Pour paste into paste tray
- Paste the wall with roller
- Apply the flexi sheet lengths edge to edge (vertically or horizontally)
- The roll edges of the flexi sheet do not always achieve a tight edge to the edge joint when fixed to walls. To obtain a tight edge tot edge joint the edges of adjacent rolls must be overlapped on the wall by approx. 10- 15mm and then cut down the centre of the overlap. The cut off edges should then be discarded, and the roll edges joined along the new clean edge line.
- Use a soft wallpaper brush to remove bubbles and creases
- Use a straight edge and trimming knife or scissors at any corners
- Remove any excess paste with a damp sponge
- Leave to dry thoroughly (24 hrs)
- The wall is now ready to hold magnets and write on with dry erase pens.

Care of surface:

- For writing use only use DRY ERASE whiteboard pens
- For increased magnetic pull use strong magnet
- For best results clean regularly with a whiteboard cleaner and conditioner
- Do not use abrasive cleaners